



### Futaba "G" (Old Style or AM)



"Female"

Found on Battery




"Male"

Found on Servos & Charger


### Futaba "J"

(New Style or FM : This connector is on newer Futaba systems, AM or FM)



"Female"

Found on Charger




"Male"

Found on Servos & Battery


### "JR"

(This connector is also used on "Hitec" & the newer "World Eng" radios with wire color changes as follows: Brown = Black & Orange = Yellow)



"Female"


Found on Charger



"Male"


Found on Servos & Battery

### Airtronics



"Female"

Found on Charger



"Male"

Found on Servos & Battery